CONTENTS

CHAPTER 1: MAINTENANCE

1. Preface 1-1
   CAUTION 1-2
   WARNING 1-3
2. Work Precautions 1-4
3. Exterior Cover Removal 1-6
4. Installation 1-9

CHAPTER 2: MACHINE SUMMARY

1. Features of the RISOGRAPH FR 2-1
2. Specifications 2-2
3. Product Compatibility 2-6
4. Cross Sectional View 2-8
5. Machine Operations 2-9
6. Paper Feed and Receiving 2-10
7. Master Removal and Feed 2-11

CHAPTER 3: MAIN DRIVE SECTION

THEORY OF OPERATION

1. Main Drive 3T-1
2. Main Motor Safety Switch 3T-2
3. Other Mechanisms 3T-3

REMOVAL & ASSEMBLY

1. Main Shaft Ass'y 3R-1
2. Drive Unit 3R-2
3. Main Motor Unit 3R-3

CHAPTER 4: FIRST PAPER FEED SECTION

THEORY OF OPERATION

1. Paper Feed Tray Mechanism 4T-1
2. Paper Feed Tray Sliding Mechanisms(A3) 4T-2
3. Paper Width Detection System 4T-4
4. Paper Feed Tray Elevation System 4T-6
5. Paper Feed Tray Safety System 4T-8
6. Paper Feed Pressure Select System 4T-9
7. First Paper Feed Rollers Rotary System
   (Activate by the paper feed clutch sensor) 4T-10
8. First Paper Feed Rollers Rotary System
   (Activate by Drum angle) 4T-12
9. Paper Pickup System 4T-14

REMOVAL & ASSEMBLY

1. Paper Feed Tray Unit 4R-1
2. Paper Size Potentiometer 4R-2
3. Paper Feed Tray Slide Motor, Paper Feed Tray Safety SW,
   Paper Feed Tray Position Sensor 4R-3
4. Scraper Unit 4R-4
5. Scraper and Pickup Rollers 4R-5
6. Paper Feed Clutch Ass'y 4R-6
7. Elevator Motor Unit 4R-7
8. Stripper Unit 4R-8
9. Stripper Pad 4R-9

ADJUSTMENT
1. Paper Width Data 4A-1
2. Position of Elevator Upper Limit Sensor 4A-2
3. Stripper Pad Pressure 4A-3
4. Position of Stack Paper Feed Switch 4A-4
5. Position of P Disc (Start-time of First Paper Feed) 4A-5
6. Paper Feed Mode (Paper Feed Clutch OFF Timing) 4A-6

CHAPTER 5: SECOND PAPER FEED SECTION

THEORY OF OPERATION
1. Second Paper Feed System 5T-1
2. Timing Rollor Up Down System 5T-2
3. Vertical Position Control System 5T-3

REMOVAL & ASSEMBLY
1. Guide Roller Unit 5R-1
2. One-way Spring and Load Spring 5R-2
3. Timing Roller 5R-3
4. Paper Guide Plate 5R-4
5. Paper Sensor PCBs (Paper Sensor and Paper Feed Det. Sensor) 5R-5

ADJUSTMENT
1. Parallelism of Timing Roller 5A-1
2. Gap between Timing Cam and Timing Lever 5A-2
3. Vertical Print Position 5A-4
4. Position of Timing Cam 5A-6

CHAPTER 6: PRESS SECTION

THEORY OF OPERATION
1. Press System (Activate by the Pressure detection sensor) 6T-1
2. Press System (Activate by Drum Angle) 6T-3
3. Pressure Regulation System 6T-5

REMOVAL & ASSEMBLY
1. Main Shaft Face Plate 6R-1
2. Pressure Link Ass'y 6R-2
3. Pressure Lever, Pressure Shaft 6R-3
4. Pressure Roller 6R-4

ADJUSTMENT
1. Installation Position of Pressure Lever 6A-1
2. Resting Position of Pressure Lever (Pressure Roller) 6A-3
3. Position of Pressure Solenoid 6A-4
4. Resting Position of Hook Lever 6A-5
5. Standard Pressure Position 6A-6
6. Position of Pressure Sensor Disc 6A-7
7. Parallelism of Pressure Roller 6A-8

CHAPTER 7: PAPER EJECTION SECTION

THEORY OF OPERATION
1. Paper Separation System 7T-1
2. Separator Positioning System 7T-2
3. Paper Ejection System 7T-3
4. Paper Ejection Guides Auto-setting System 7T-4
5. Paper Receiving System 7T-6

REMOVAL & ASSEMBLY
1. Separator 7R-1
2. Separation Air Pump 7R-2
3. Suction Clutch Unit 7R-3
4. Suction Clutch 7R-4
5. Paper Receiving Tray 7R-5
6. Suction Unit 7R-6
7. Transfer Belt 7R-7
8. Wing Motor 7R-8
9. Jump Wing Sw, Wing Cam Shaft 7R-8
10. Paper Receiving Sensors (Send) 7R-9
11. Separation Fan and Stocker Unit (A3 MACHINE) 7R-10
12. Separation Fan (B4/A4 MACHINE) 7R-11
13. Paper Receiving Sensors (Receive) 7R-12

ADJUSTMENT
1. Position of Separator 7A-1
2. Position of Separation Pump Pulley Plate
(Timing Adjustment of Separator Air Blow) 7A-2

CHAPTER 8: DRUM SECTION

THEORY OF OPERATION
1. Drum Rotation Check System 8T-1
2. Drum Locking System 8T-4
3. Master Presence Check System 8T-6
4. Drum Type, Ink Bottle Detecting System 8T-7
5. Ink Supply System 8T-8

REMOVAL & ASSEMBLY
1. Lock Solenoid 8R-1
2. Squeegee Unit 8R-2
3. Ink Pump Unit, Ink Bottle SW 8R-3
4. Inking Motor 8R-6
5. Drum PCB 8R-6
6. Squeegee Belt 8R-7
7. Squeegee Roller 8R-8
8. Screens <A3/Ledger> 8R-9
9. Screens <B4/A4/Legal> 8R-10
10. Drum Body 8R-11
11. Clamp Plate Ass'y 8R-12

ADJUSTMENT
1. Squeegee Gap 8A-1
2. Squeegee Pressure Balance 8A-2
3. Position of Ink Blocking Plates 8A-3
4. Drum Position A (Drum Home Position) 8A-4
5. Position of Drum Holder 8A-5

CHAPTER 9: PAPER JAMS

1. Paper Jams 9-1
1) Paper Jam in the First Paper Feed Area 9-1
2) Paper Jam in the Second Paper Feed Area / Paper Jam under the Drum 9-1
3) Paper Jam at Paper Receiving Sensor 1 9-2
4) Paper Jam at Paper Receiving Sensor 2 9-2

- Timing Chart - 9-3
Paper Jam in the First Paper Feed Area 9-3
Paper Jam in the Second Paper Feed Area / Paper Jam under the Drum 9-4
Paper Jam at Paper Receiving Sensor 1 9-5
Paper Jam at Paper Receiving Sensor 2 9-6

2. Flow of Printing Operations 9-7
- Timing Chart - 9-8
Printing Start Timing Chart (P disc, Pressure sensor disc) 9-8
Printing Start Timing Chart (Drum angle) 9-9
Printing Stop Timing Chart (P disc, Pressure sensor disc) 9-10
Printing Stop Timing Chart (Drum angle) 9-11

3. Cross Sectional Diagram of Paper Feed & Receive 9-12

CHAPTER 10: MASTER CLAMP SECTION

THEORY OF OPERATION

1. Clamp Plate Opening System 10T-1
2. Clamp Plate Closing System 10T-3

REMOVAL & ASSEMBLY

1. Clamp Unit 10R-1
2. Clamp Motor 10R-2
3. Clamp Solenoid 10R-2

CHAPTER 11: MASTER REMOVAL SECTION

THEORY OF OPERATION

1. Master Presence on Drum Check System 11T-1
2. Clamp Plate Opening System 11T-2
3. Master Removal System 11T-4
4. Disposed Master Check System 11T-6

REMOVAL & ASSEMBLY

1. Master Removal Unit 11R-1
2. Master Removal Solenoid, Master Removal Hook & Vertical Transport Roller (Down) . 11R-3
3. Master Removal Sensor, Master Loading Sensor,
Master Removal Hook Sensor & Disposal Box Master Sensor 11R-4
4. Disposal Box Master Sensor (Send) 11R-5
5. Master Removal Fan 11R-6

ADJUSTMENT

1. Projected Position of Master Removal Hooks 11A-1
2. Position of Master Removal Hook Sensor 11A-2

CHAPTER 12: FLAT BED SCANNING SECTION

THEORY OF OPERATION

1. Scanner Table Setting System 12T-1
2. Flat Bed Original Detection System 12T-2
3. Image Scanner Initial Movement System 12T-4
4. Image Scanning System - in Auto Scanning Contrast Adjustment Mode 12T-6
5. Image Scanning System - Without Book Processing Feature & ADF 12T-8
6. Pre-Scanning System - With Book Processing Feature & Without ADF 12T-10
7. Image Scanning System - With Book Processing Feature & Without ADF 12T-12

REMOVAL & ASSEMBLY
1. Stage Glass 12R-1
2. Image Scanner 12R-2
3. Image Scanner Carriage 12R-3
4. Flat Bed Read Pulse Motor 12R-4
5. FB-Scanner Belts 12R-5
6. Image Flexible Wire 12R-6
7. Flat Bed Original Detection Sensor 12R-6

ADJUSTMENT
1. Scanning Start Position 12A-1
2. Horizontal Scanning Position 12A-2
3. Image Elongation/Shrinkage Correction 12A-3

CHAPTER 13: ADF IMAGE SCANNING SECTION

THEORY OF OPERATION
1. ADF Original Loading System 13T-1
2. ADF Image Scanning System - in Auto Scanning Contrast Adjustment Mode 13T-4
3. ADF Image Scanning System 13T-6

REMOVAL & ASSEMBLY
1. ADF Glass, ADF Original IN Sensor (receive), ADF Switch, White Roller 13R-1
2. Original IN Sensor (send), ADF Transfer Roller, Original Pickup solenoid 13R-2
3. ADF Original Detection Sensor, Original Registration Sensor 13R-4
4. ADF Pickup (Upper) Ass'y, ADF Stripper Ass'y 13R-4
5. ADF Read Pulse Motor 13R-6
6. Original Pickup Motor, Original OUT Sensor 13R-6

ADJUSTMENT
1. Sensitivity of Original IN Sensor 13A-1
2. Scanning Start Position 13A-2
3. Horizontal Scanning Position 13A-3
4. Image Elongation/Shrinkage Correction 13A-4

CHAPTER 14: CUTTER SECTION

THEORY OF OPERATION
1. Master Cutting System 14T-1

REMOVAL & ASSEMBLY
1. Cutter Unit 14R-1
2. Master Positioning Sensor 14R-2

CHAPTER 15: MASTER SETTING SECTION

THEORY OF OPERATION
1. Thermal Print Head Positioning System 15T-1
2. Master Setting System 15T-3
3. Master Free Feeding System 15T-7

REMOVAL & ASSEMBLY
1. Set Guide Plate 15R-1
2. Thermal Pressure Motor Unit 15R-2
3. Thermal Pressure Motor 15R-3

CHAPTER 16: MASTER MAKING SECTION

THEORY OF OPERATION

1. Master Making System 16T-1

REMOVAL & ASSEMBLY

1. Write Roller 16R-1
2. Thermal Print Head 16R-3

ADJUSTMENT

1. Thermal Power of Thermal Print Head 16A-1
2. Image Elongation/Shrinkage Correction
   (Write Pulse Motor Speed Adjustment) 16A-3

CHAPTER 17: MASTER CLAMP & LOADING SECTION

THEORY OF OPERATION

1. Master Clamping System 17T-1
2. Master On-Drum Loading System 17T-3
3. Master Post-Cutting Feeding System 17T-6
4. Post-Master-Miscut Operation 17T-8

REMOVAL & ASSEMBLY

1. Loading Fan <B4/A4/Legal> 17R-1

CHAPTER 18: SC CONTROLLER SECTION

1. Specifications
   - 1-1. Specifications 18-2
   - 1-2. Port Specification 18-2
2. Installation (Hardware)
   - 2-1. Checking Package Contents 18-5
   - 2-2. Computer System Requirements 18-5
   - 2-3. Connecting the cables 18-6
   - 2-4. Expanding Memory Volume 18-7
3. Installation (Printer Drivers)
   - 3-1. Macintosh (OS 8.1) 18-8
   - 3-2. Windows 95/98 18-11
   - 3-3. Windows NT4.0 18-15
4. Firmware Program
   - 4-1. Firmware Program Version Check 18-20
   - 4-2. Firmware Program Upgrading 18-22
5. Trouble-Shooting Tips
   - 5-1. Isolating Fault Area 18-27
   - 5-2. Test Print 18-32
   - 5-3. Error Indicator on SC Panel 18-33
6. Disassembly and Re-Assembly
   - 6-1. SC Main PCB 18-35
   - 6-2. SC Power Supply PCB 18-37
   - 6-3. I/F-Port PCB 18-37
7. SC Section Appendix
   - 7-1. Theory of Data Processing 18-38
   - 7-2. CD-ROM File Contents 18-39
   - 7-3. Description of SC Panel LEDs 18-40
   - 7-4. Description of Power Select Switch and SC Panel Button 18-41

CHAPTER 19: OTHER OPERATION & FUNCTION

1. Confidential Mode 19-1
2. Automatic Idle 19-3
3. Multi Up Printing (2, 4, 8 and 16up) 19-4
4. TPH Test Pattern Print Out 19-5
5. Auto Power-Off 19-6
6. Preventive Maintenance Indication 19-7
7. Job Separator Activate Signal 19-8

CHAPTER 20: IMAGE PROCESSING

THEORY OF OPERATION

1. Image Processing Flow 20T-1
2. Line Mode Processing 20T-2
3. Photo Processing 20T-3
4. Line/Photo Mixing Mode (“Duo” Mode) 20T-4
5. Shading Compensation 20T-5
6. Gamma Compensation 20T-6
7. Book Processing Function 20T-7
8. Fine Enhancement 20T-9
9. Automatic Scanning Contrast Control 20T-11

ADJUSTMENT

1. Gamma Compensation 20A-1
2. Slice Level Adjustment 20A-2
3. Fine Enhancement Adjustment 20A-2

CHAPTER 21: ADVICE DISPLAYS

ADVICE DISPLAYS

1. Trouble Messages (T Display) 21-1
2. Trouble Messages (Others) 21-5
3. Setting Confirmation Messages 21-8
4. Change-of-Consumables Messages 21-9

CHAPTER 22: TEST MODE

TEST MODE

1. Operation Procedures 22-1
2. Testing Sensor and Switch 22-4
3. Testing Motor and Solenoid 22-5
4. Memory Clear and Counter Stop, etc. 22-6
5. Sequential Operation Test 22-7
6. Other Test mode 22-8
7. Memory Switch 22-10
8. Memory Switch (Image Adjustment) 22-13

USER MODE

1. Operation Procedures 22-16
2. Initial Operation Settings 22-18

CHAPTER 23: ELECTRICAL COMPONENTS

1. Motors 23-1
2. Solenoids & Clutches 23-2
3. Fan 23-3
4. Sensors 23-4
5. Switches 23-6
6. Other 23-8

CHAPTER 24: DESCRIPTION OF PCBs

1. Block Chart
   - 1-1. FR2950 24-1
   - 1-2. FR3950 24-2
   - 1-3. FR3950a 24-3
2. Location of PCBs
   - 2-1. FR2950 24-4
   - 2-2. FR3950 24-5
   - 2-3. FR3950a 24-6
   - 2-4. PCB Function Detail 24-7
3. System PCB
   - 3-1. System PCB 3 (FR B4/A4) 24-8
   - 3-2. System PCB 4 (FR A3) 24-16
4. Image Processing PCB (CIPDF) 24-24
5. Motor Control PCB
   - 5-1. Motor Control PCB 2 (FR B4/A4) 24-27
   - 5-2. Motor Control PCB 3 (FR A3) 24-29
6. Drum Control PCB 24-31
7. ADF PCB 24-33
8. Flat Bed PCB 2 24-35
9. Trimming PCB2 24-37
10. Panel Control PCB
    - 10-1. Panel Control PCB 2 (FR B4/A4) 24-38
    - 10-2. Panel Control PCB 3 (FR A3) 24-40
11. Option PCB A III 24-42
12. Power Supply PCB
    - Fuse Replacement 24-45
    - 12-1. Power Supply PCB VII N100V (Nichicon) 24-46
    - 12-2. Power Supply PCB VII H100V (Hitachi) 24-47
    - 12-3. Power Supply PCB VI N 200V ;CE (Nichicon) 24-48

FR3950a only

13. SC Main PCB 24-50
14. I/F Port PCB 24-53
15. SC Power Supply PCB;SC3K 24-55

APPENDIX

1. Machine Model Setting APX-1